

In this installation you will be using the existing holes in the hood that the factory rubber seal installs into.

- 1 Lift the hood and remove any dirt or debris. Remove the clips from the rubber seal where hood protector will be mounted.
- 2 Position the hood protector in place by sliding the mounting tabs in between the rubber seal and the hood, lining up the holes with the holes in the hood. Using the mounting screws with washers, attach the hood protector to the hood. Tighten just enough to hold the hood protector in place.
- 3 Close the hood **CAREFULLY** to check the fit. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until it is centered. When you are satisfied the hood protector is in place, tighten the screws until snug. **DO NOT OVER TIGHTEN this may damage your new hood protector.**

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

KIT CONTAINS:
HOOD PROTECTOR
8 MOUNTING SCREWS
8 WASHERS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER

In this installation you will be using the existing holes in the hood that the factory rubber seal installs into.

- 1 Lift the hood and remove any dirt or debris. Remove the clips from the rubber seal where hood protector will be mounted.
- 2 Position the hood protector in place by sliding the mounting tabs in between the rubber seal and the hood, lining up the holes with the holes in the hood. Using the mounting screws with washers, attach the hood protector to the hood. Tighten just enough to hold the hood protector in place.
- 3 Close the hood **CAREFULLY** to check the fit. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until it is centered. When you are satisfied the hood protector is in place, tighten the screws until snug. **DO NOT OVER TIGHTEN this may damage your new hood protector.**

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

KIT CONTAINS:
HOOD PROTECTOR
8 MOUNTING SCREWS
8 WASHERS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER

In this installation you will be using the existing holes in the hood that the factory rubber seal installs into.

- 1 Lift the hood and remove any dirt or debris. Remove the clips from the rubber seal where hood protector will be mounted.
- 2 Position the hood protector in place by sliding the mounting tabs in between the rubber seal and the hood, lining up the holes with the holes in the hood. Using the mounting screws with washers, attach the hood protector to the hood. Tighten just enough to hold the hood protector in place.
- 3 Close the hood **CAREFULLY** to check the fit. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until it is centered. When you are satisfied the hood protector is in place, tighten the screws until snug. **DO NOT OVER TIGHTEN this may damage your new hood protector.**

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

KIT CONTAINS:
HOOD PROTECTOR
8 MOUNTING SCREWS
8 WASHERS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER

In this installation you will be using the existing holes in the hood that the factory rubber seal installs into.

- 1 Lift the hood and remove any dirt or debris. Remove the clips from the rubber seal where hood protector will be mounted.
- 2 Position the hood protector in place by sliding the mounting tabs in between the rubber seal and the hood, lining up the holes with the holes in the hood. Using the mounting screws with washers, attach the hood protector to the hood. Tighten just enough to hold the hood protector in place.
- 3 Close the hood **CAREFULLY** to check the fit. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until it is centered. When you are satisfied the hood protector is in place, tighten the screws until snug. **DO NOT OVER TIGHTEN this may damage your new hood protector.**

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

KIT CONTAINS:
HOOD PROTECTOR
8 MOUNTING SCREWS
8 WASHERS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER