

This product is designed to be placed on the chrome trim surface of the door, just above the weather stripping.

- 1** Clean surface thoroughly where product is to be installed with alcohol pads provided and allow to dry.
- 2** Hold part in place and lightly mark where it will be installed.
- 3** Peel 1" of the red backing from both ends of the adhesive strip and press into place along mark.
- 4** When positioned, remove the remaining tape backing and press the part firmly along entire length of the flange using a soft cloth with a continuous rubbing motion. *BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-SURFACE CONTACT. FIRM PRESSURE CREATES MAXIMUM CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS.*

IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT (See Insert)!

**IMPORTANT: Must be cleaned with a SOFT cloth and soap and water ONLY!
Using abrasive cleansers, chemicals or solvents will VOID the warranty on this product.**

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

This product is designed to be placed on the chrome trim surface of the door, just above the weather stripping.

- 1** Clean surface thoroughly where product is to be installed with alcohol pads provided and allow to dry.
- 2** Hold part in place and lightly mark where it will be installed.
- 3** Peel 1" of the red backing from both ends of the adhesive strip and press into place along mark.
- 4** When positioned, remove the remaining tape backing and press the part firmly along entire length of the flange using a soft cloth with a continuous rubbing motion. *BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-SURFACE CONTACT. FIRM PRESSURE CREATES MAXIMUM CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS.*

IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT (See Insert)!

**IMPORTANT: Must be cleaned with a SOFT cloth and soap and water ONLY!
Using abrasive cleansers, chemicals or solvents will VOID the warranty on this product.**

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219

This product is designed to be placed on the chrome trim surface of the door, just above the weather stripping.

- 1** Clean surface thoroughly where product is to be installed with alcohol pads provided and allow to dry.
- 2** Hold part in place and lightly mark where it will be installed.
- 3** Peel 1" of the red backing from both ends of the adhesive strip and press into place along mark.
- 4** When positioned, remove the remaining tape backing and press the part firmly along entire length of the flange using a soft cloth with a continuous rubbing motion. *BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-SURFACE CONTACT. FIRM PRESSURE CREATES MAXIMUM CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS.*

IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT (See Insert)!

**IMPORTANT: Must be cleaned with a SOFT cloth and soap and water ONLY!
Using abrasive cleansers, chemicals or solvents will VOID the warranty on this product.**

Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219