

## 2019+ DODGE RAM TAILGATE J-CLIP INSTALLATION

1. Read all instructions before installing.
2. Loosen or remove the access panel on inner surface of the tailgate.
3. Snap J-Clip on to upper edge of access panel and center it along the length of the tailgate.
4. Re-attach and tighten access panel hardware.
5. Using a clean lint-free cloth, clean the attachment surface of J-Clip using isopropyl alcohol.  
If the cloths become visibly soiled, replace them with clean ones.

**NOTE: THE ATTACHMENT SURFACE TEMPERATURE SHOULD BE 68° F OR HIGHER IN ORDER FOR THE ADHESIVE STRIPS TO ACHIEVE MAXIMUM ADHESION. ALSO, NEVER CONTAMINATE THE ADHESIVE BY TOUCHING IT WITH YOUR FINGERS.**

6. Apply adhesive promotor to J-Clip.
7. Remove the film and align the edge of the bed liner tailgate section to the top edge of the tailgate.
8. Firmly press the bed liner tailgate for 15 seconds to ensure adhesive attachment.

