

1997-06 TJ
Mirror Relocation Brackets
11025.03 - Black
11026.03 - Stainless Steel



Page 1

Step 1. Remove the three bolts that retain the factory door mirror. Remove the factory mirror.



Step 2. Remove the two side door hinge bolts. The factory uses threadlock to retain these bolts, so some effort may be required.



Step 3. Using the included hardware, install the relocation bracket using the existing factory door hinge bolt holes. Install both bolts loosely. Note that the relocation bracket points forward.



Step 4. Tighten both bolts snugly.



Step 5. The relocation bracket is now installed.



Step 6. Place the factory mirror onto the relocation bracket, taking care to align the mounting bolt holes. Using the included hardware, insert the bolts through the mirror and bracket mounting holes.



Step 7. Place one washer on each bolt, followed by one nut (included). Tighten the nuts snugly, taking care not to over tighten.



Step 8. Installation is now complete. Repeat procedures for other side.

