



#33112 Locking Pin Set

Installation Instructions and Notes

Pin Capacity

14,000lbs Max.

System Capacities

Be sure to double check the capacity of your entire towing hitch system. Use the trailer coupler capacity, or the capacity listed above, **whichever is lower**. If trailer coupler capacity is unknown, do not exceed the maximum towing capacity which is stamped on either your trailer balls or accessories.

Applications

These pins are designed for over-the-road towing within the stated capacities.

Mounting

These pins can only be used with the Husky® System. If you are not yet familiar with how your Husky® System works, it is recommended that you familiarize yourself with operating instructions prior to installing and using these pins. Failure to do so can result in possible accidents and/or injuries.

Operating Instructions for the Husky® System

*Before operating, inspect for proper operation, worn, damaged or missing parts and secure mounting. Correct as required before use. Be sure to fully inspect the vehicle's receiver hitch, the Husky® Platform and it's respective hardware. If you doubt the condition of any of the Husky®'s parts or accessories or your vehicle's hitch system – **do not** tow and contact your sales dealer for replacement parts.*

Installation:

1. *Replace your current receiver hitch pin with the shorter locking pin included with this kit. To remove and re-install the lock, simply insert the included key and turn to lock and unlock the set. Your old receiver pin will no longer be used, as your Husky® Platform hitch is now secured to the tow vehicle's hitch.*
2. *To secure your Husky® accessory to the platform, install the longer locking pin in to the **bottom** hole of the accessory you wish to secure. When correctly installed, the upper hole of the accessory will be secured with the standard yellow pin which was included with your Husky® kit. The bottom hole will now be secured with your locking pin.*

Note: *These locking pins do not promise or guarantee the security of your vehicles, trailers, hitches or contents. Husky® and the manufacturer cannot be held liable for any damages or losses as a result of theft or vandalism of any property. **Always double-check your towing apparatus and hardware before resuming towing to be sure that they are in good working condition and installed correctly.***