



Tonneau Cover 1987-1995 YJ Wrangler

Part Number: TN10015, TN10037, & TN10215

Kit Components

1 - Tonneau Cover

- Read all instructions carefully prior to starting installation.
- The factory soft top bow assembly **MUST** be installed on the vehicle.
- We recommend installing this Tonneau Cover in temperatures 70F (21C) and above.
- Do not over-stress the straps. Failure to comply may damage the Tonneau Cover or straps.
- Drilling may be required.



1. Start by removing the factory soft top and windows. The Tonneau Cover will not fit with the soft top installed.
Set aside the tailgate bar for later use.
2. Remove the plastic pin from the soft top slider track. This will allow the bow assembly to slide forward. Fold the bow assembly back.
3. Lay the Tonneau Cover over the rear seat area and wrap around the roll bar at the rear corners of the Jeep.
Do not affix the hook and loop fasteners at this time.
4. Slide the your factory tailgate bar onto the sewn-in plastic strip at the back of the Tonneau Cover and clip it into the tailgate bar retainers on the body rail.
5. Starting at the rear corner, tuck the sewn in plastic strips on both sides of the Tonneau Cover into the tub rails.
6. Wrap the straps around the front of the roll bar and attach the buckle.
7. Affix the hook and loop fasteners onto the roll bar.
8. Make any adjustments necessary to ensure the Tonneau Cover is centered and fits properly. Creases in the fabric will fade away once the top is installed.
9. Small adjustments to the Tonneau Cover may be necessary once it warms up and any creases are smoothed out.

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure