

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Chevrolet	Tracker
Suzuki	Grand Vitara
Suzuki	Vitara
Suzuki	XL-7

## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below


**S1** - Behind driver side taillight housing

**S2** - Behind passenger side taillight housing

**S3** - Behind driver side rear access panel



## CUSTOM WIRING CONNECTOR



## NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

None

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Suzuki Vitara / Grand Vitara / Chevrolet Tracker

### Step 1

Inside of the driver side tire jack compartment, locate the vehicle taillight wiring harness connector (A).

### Step 2

Locate the 6-pin connector taped to the vehicle wiring harness (B). Remove the tape on the vehicle connector and insert the custom wiring harness into the vehicle connector. Make sure the connector is fully inserted with the locking tabs in place.

### Step 3

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape.



### Step 4

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

### Step 5

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.



## Suzuki XL-7

### Step 1

Open the vehicle tailgate. Remove the four screws securing the storage compartment to the floor. Remove the storage compartment by lifting the back first (C).

### Step 2

Remove the two plastic push clips from the bottom rear edge of the left inner trim panel. Pull the rear edge of the left trim panel away from the body (D).

### Step 3

Pull back the left trim panel to locate the vehicle taillight wiring harness connector under the rear blower motor. The connector will be similar to the one on the custom wiring harness. Insert the custom wiring harness into the vehicle connector. Make sure the connector is fully inserted with the locking tabs in place (E,F).

### Step 4

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape.

### Step 5

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

### Step 6

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.